IKELITE VIDEO CASE

SUPPLEMENTAL INSTRUCTIONS FOR

#6038.85 SONY DCR-SR37, 47, 57, 67, 77, 87

This supplemental set of instructions describes additional features specific to your housing model. Prior to testing the system in the water, please read this supplement along with the general instruction manual to become familiar with its features and functions.

Ikelite Video Cases are slightly negative in salt water for stability. This housing has been water pressure tested at the factory and has a working depth of 60m (200').





HOUSING CONTROLS

- Power On/Off
- Start/Stop/Mode
- Power Zoom
- Photo
- LCD Screen Control #1
- LCD Screen Control #2
- LCD Screen Control #3
- LCD Reversing Circuit On/Off

MAIN O-RING #0109

O-rings last several years if properly maintained. Control seals should not need to be replaced as long as the control shafts are kept clean and lightly lubricated.

PREPARATION

PACKAGED WITH HOUSING

- External UR/Pro Color Filter
  The installation and usage of the external UR/Pro color filter is described in the general instruction manual.
- Silicone Lubricant



External Color Filter

LCD MONITOR / EXTERNAL MIRROR

The camera's LCD monitor can be viewed from the rear of the housing, using the external mirror featured on the side of the housing.

Open the LCD monitor on the camera, rotate 180°, and then press it back against the side of the camera. The external mirror is hinged so that it can be opened to reflect the image from the camera's LCD monitor for viewing from the rear of the housing.

During transportation, please remember to close the mirror by pressing it against the rubber on the lid snap.

BATTERY AND TAPE

Install a fully charged Sony battery on the camera:
Sony NP-FH50, NP-FH60, NP-FH70

Other brand batteries may not fit inside the housing.

Make sure you have loaded an appropriate digital cassette tape in the camera.

OPTIONAL WIDE ANGLE LENS

The housing's port accepts optional 67mm threaded waterproof Wide-Angle lenses such as the Ikelite #6420 W-20, Epoque DCL-20 and Inon UWL-100 Type 2 and Sea&Sea (58070). These waterproof lenses secure to the outside of the lens port.

Should you elect to use the optional Ikelite #6420 W-20, Epoque, Inon or Sea&Sea lens, carefully thread the waterproof lens on the front of the lens port. The lens threads are very fine; **DO NOT** cross thread. It should screw on very easily. If it is difficult to turn, you are cross threading.

POWER ON/OFF - IMAGE REVERSING CIRCUIT

A single control on the housing operates both the Power ON/OFF and Image Reversing Circuit.
Secure the camera to the tray and partially slide the camera and tray inside the housing so you can connect the cable from the Power/Image Reversing circuitry to the AV Out port on the camera.

Power ON/OFF Switch

If the camera is OFF, hold the Power button down for one second to turn the camera ON. When turning the camera OFF, there is a 5-minute standby power down delay that occurs when the reversing circuit is ON during power down. To avoid the 5-minute power down delay, turn the Reversing Circuitry OFF and then hold the the Power button down for three seconds to turn the camera OFF.

Image Reversing Circuit

The circuit reverses (flips) the image and words on the LCD screen so that when the image is reflected in the external mirror, it appears correct left-to-right.

Functions Locked Out

When the reversing circuit is ON, some camera functions may be locked out. To activate the locked out functions, temporarily turn the Reversing Circuit OFF, change the locked out function on the camera, and then turn the Reversing Circuit back ON.

FINAL PREPARATION

Remove the lens cap and cord from the camera. Otherwise, they may interfere with the housing seal.

The camera's auto focus feature is utilized underwater. For best results, move in close to your subject and use the wide angle range to shoot thru as little water as possible. The full zoom range is accessible underwater.

Turn the camera's built-in flash OFF. Chart shows recommended initial settings underwater.

CAMERA		SETTING
Power On/Off	–	Camera (On)
Zoom Lever	–	Wide Angle Setting
Focus	–	Auto Mode
Exposure	–	Auto Mode
Program AE	–	Auto Mode
Shutter Speed	–	1/60 Normal
White Balance	–	Auto Mode (see section)
Steady Shot	–	Off
Built-in Flash	–	Off

WHITE BALANCE

The LCD controls that extend from the back and side of the housing are designed to access all P-MENU boxes. The primary reason for these is to adjust the WHITE BALANCE controls.

Initially set the white balance to Auto. Use the touch screen controls on the housing to change white balance.

Color Filter: When using the color filter (during the day), set camera white balance to Indoor for 0-15 foot depth. For 15-80 foot depth, set white balance to Outdoor.

Video-Lite: When using optional Video Lite at NIGHT, set the camera white balance to the Indoor position. During the DAY, use the Outdoor setting for subjects beyond 4-5 feet and the Indoor setting for closer subjects.

INSTALLATION

CAMERA TRAY

The camera mounts to the tray, which extends from the back plate of the housing. **DO NOT** remove the tray from the back plate.

Position the camera against the two stabilizing pins on the tray and secure with the camera mounting bolt. The camera should fit easily on the tray and should be parallel with the sides of the tray.



INSERTING THE CAMERA

Check that the o'ring is clean and properly positioned on the lip of the clear housing back plate.

Once the camera is mounted to the tray as shown above, pull the housing controls out to provide clearance for installing the camera. Partially slide the camera into the housing so you can connect the reversing circuit cable to the Remote port on the camera, (see Image Reversing Circuit).

DO NOT force this installation; the camera and tray should slide easily into place so the housings back plate o'ring is resting against the main housing body. In this position the lid snaps can be positioned over the lid hooks on the housing back plate and snapped into position to seal the housing.

HOUSING CONTROLS

Slide the housing controls back in place making sure they properly align with the camera functions.

Operate each control to see how it works with the camera. Some controls such as start/stop will be used frequently. Other controls may seldom be utilized. Refer to your camera owner's manual for the proper function of each camera control. Look thru the back to be sure that you can see into the viewfinder.

When using the housing controls, especially the start/stop, do NOT use excessive force because you could damage the camera.

CAUTION

Remove the lens cap and cord from the camera. Otherwise, the cord may interfere with the housing seal.
If the housing controls are not properly positioned, they could interfere with the housing seal.

IKELITE UNDERWATER SYSTEMS
50 West 33rd Street • PO Box 88100 • Indianapolis, IN 46208 USA • 317.923.4523
Email: ikelite@ikelite.com • www.ikelite.com

6038.85-01-0509